



## PX1.5.4 and PX1.5.7 Supported Models List

<b>Model</b>
DPCS16A-32BS4343
DPCR20-20
DPCR20-20L
DPCR20-30L
DPCR20A-16
DPCR20A-30L6
DPCR20A-32
DPCR2X8-15
DPCR2X8A-16
DPCR2X8A-20
DPCR8-15
DPCR8-15-J
DPCR8A-16
DPCR8A-20L6
DPCR8A-20L6-J
DPCS12-20
DPCS12-20L
DPCS12-20L-J
DPCS12-30L
DPCS12-30L-J
DPCS12A-16
DPCS20-20
DPCS20-20L
DPCS20-30L
DPCS20-30L-J
DPCS20A-16
DPCS20A-20L6
DPCS20A-30L6
DPCS20A-30L6-V2
DPCS20A-32
DPXR20-20
DPXR20-20L
DPXR20-30L
DPXR20A-16
DPXR20A-20L6

DPXR20A-30L6
DPXR20A-32
DPXR4X1A-16NP
DPXR8-15
DPXR8-15-J
DPXR8-20
DPXR8-20-5
DPXR8-20L
DPXR8A-15AU
DPXR8A-15AU-1
DPXR8A-16
DPXR8A-16AU-M
DPXR8A-16C
DPXR8A-16-M
DPXR8A-16NP
DPXR8A-20AU
DPXR20A-32-K1
DPXR20A-32-K2
DPXR8A-20AU-M
DPXR8A-20L6
DPXR8A-20L6-J
DPXS12-15
DPXS12-20
DPXS12-20L
DPXS12-20L-J
DPXS12-30L
DPXS12-30L-J
DPXS12A-16
DPXS12A-20AU
DPXS12A-20AU-M
DPXS12A-20L6
DPXS12A-30L6-M
DPXS12A-30L-M
DPXS12A-32
DPXS12A-32AUA
DPXS12A-32AUA-M
DPXS12B-20L-5
DPXS20-20

DPXS20-20L
DPXS20-30L
DPXS20-30L-J
DPXS20-30LP
DPXS20A-16
DPXS20A-16AU-M
DPXS20A-16AU-MT
DPXS20A-20AU
DPXS20A-20AU-M
DPXS20A-20AU-MT
DPXS20A-20L6
DPXS20A-30L6
DPXS20A-30L6-J
DPXS20A-30L6P
DPXS20A-32
DPXS20A-32AUA
DPXS20A-32AUA-M
DPXS20A-32-M
DPXS24A-16T
PX-3211
PX-3220
PX-3270
PX-3370
PX-3411
PX-3420
PX-3423
PX-4080T
PX-4100
PX-4102
PX-4104
PX-4104A1
PX-4104A2
PX-4104N
PX-4120
PX-4197
PX-4197-C1
PX-4198
PX-4198-C1

PX-4301
PX-4307
PX-4307A1
PX-4307A2
PX-4307N
PX-4314
PX-4316
PX-4318
PX-4320
PX-4320-A1
PX-4322
PX-4367
PX-4384
PX-4386
PX-4397
PX-4397A1
PX-4397A2
PX-4397N
PX-4464
PX-4464T
PX-4469
PX-4469N
PX-4469T
PX-4469T-M2
PX-4496
PX-4520
PX-4520-C1
PX-4521-C1
PX-4522
PX-4523
PX-4523U
PX-4523U-A1
PX-4523U-A2
PX-4524
PX-4525
PX-4528
PX-4528N
PX-4530

PX-4530N
PX-4532
PX-4534
PX-4535
PX-4545-C1
PX-4551
PX-4551-K3
PX-4551-K5
PX-4551N
PX-4551V
PX-4551X
PX-4621
PX-4630
PX-4633
PX-4820
PX-4820A1
PX-4820A2
PX-4820N
PX-4917
PX-4917A1
PX-4917A2
PX-4917A2U
PX-4917A2V
PX-4917N
PX-5119
PX-5139T-C3
PX-5139T-E1C3
PX-5170
PX-5192C-A0
PX-5198
PX-5273
PX-5274
PX-5297
PX-5297T
PX-5301
PX-5314
PX-5315
PX-5318

PX-5318A2
PX-5341
PX-5367
PX-5370
PX-5371
PX-5384
PX-5395U
PX-5397
PX-5397A1
PX-5397A2
PX-5397-K1
PX-5397-K2
PX-5397N
PX-5464
PX-5464-K1
PX-5464-K2
PX-5464T
PX-5464TE
PX-5466
PX-5469
PX-5469A2
PX-5469A2T
PX-5469A2T-A9
PX-5469N
PX-5469T
PX-5475T
PX-5483
PX-5496
PX-5496-K1
PX-5496-K2
PX-5501
PX-5508
PX-5510
PX-5514
PX-5520
PX-5520-K3
PX-5520-K5
PX-5521

PX-5522
PX-5522-K1
PX-5522-K2
PX-5523
PX-5523-A1
PX-5524
PX-5524P
PX-5525
PX-5528
PX-5528E
PX-5528N
PX-5530
PX-5530N
PX-5532
PX-5532E
PX-5534
PX-5534E
PX-5535
PX-5547
PX-5547-K1
PX-5547-K2
PX-5550
PX-5551
PX-5551N
PX-5551NB
PX-5551X
PX-5616
PX-5616-L139
PX-5628I
PX-5628I-A1
PX-5628N
PX-5630
PX-5630-L139
PX-5633
PX-5635
PX-5652
PX-5652-A5
PX-5652P

PX-5660
PX-5660P
PX-5802T
PX-5804T
PX-5804T-E1
PX-5805T
PX-5805T-C3
PX-5805T-E1
PX-5805T-E1C3
PX-5806T
PX-5806T-E1
PX-5807T-C3
PX-5807T-E1C3
PX-5810
PX-5811T
PX-5807T-E1
PX-5807T
PX-5812
PX-5820
PX-5820A1
PX-5820A2
PX-5820N
PX-5820T
PX-5902T
PX-5906T
PX-5917
PX-5917A1
PX-5314-K1
PX-5314-K6
PX-5917A2
PX-5318-K1
PX-5318-K2
PX-5917N
PX-5917T
PX-5924

For Further information, if you model is not listed in the document, please contact Raritan Support.